


Power Supply

+ -



RS232 To RS485 Converter

485 - + 485

VCC GND FGN COM NC NO WIG0 WIG1 RXD TXD GND

SEN+ SEN- 485- 485+ GND EXIT

VCC GND FGN COM NC NO WIG0 WIG1 RXD TXD GND

SEN+ SEN- 485- 485+ GND EXIT

